Nortel Business Secure Router 252 — Fundamentals

BSR252

Business Secure Router

Document Number: **NN47923-301**

Document Version: **1.2**

Date: **May 2007**

NORTEL

Copyright © Nortel 2005–2006

All rights reserved.

The information in this document is subject to change without notice. The statements, configurations, technical data, and recommendations in this document are believed to be accurate and reliable, but are presented without express or implied warranty. The information in this document is proprietary to Nortel.

Trademarks

Nortel, Nortel (Logo), the Globemark, and This is the way, This is Nortel (Design mark) are trademarks of Nortel.

Microsoft, MS, MS-DOS, Windows, and Windows NT are registered trademarks of Microsoft Corporation.

All other trademarks and registered trademarks are the property of their respective owners.

Contents

Preface 7

Before you begin 7
Text conventions 7
Acronyms 7
Related publications 8
Hard-copy technical manuals 8
How to get help 9

Chapter 1
Introducing the Business Secure Router 11

Chapter 2
Hardware installation. 13

2.1 Front panel 14
2.2 Rear panel 15

Chapter 3
Setting up your computer IP address 17

3.1 Static or dynamic configuration (Windows 2000/NT/XP) 17
3.2 Checking your computer IP address 19

Chapter 4
Configuring your Business Secure Router 21

4.1 Accessing your Business Secure Router via the WebGUI 21
4.2 Using the wizard to configure for internet access 24
Internet Connection with PPPoE 26
Internet Connection with RFC 1483 26
Internet Connection with ENET ENCAP 27
Internet Connection with PPPoA 28

4.3 Test your internet connection 32

Chapter 5
User Notes 33

General Notes 33
General 33
Firewall 34
NAT 34
VPN Client Termination 34
Security 36
Routing 36
Advanced Router Configuration 37
Setting up the router when the system has a server 37
Connecting two sites to establish a virtual private network 37
Adding IP telephony to a multi-site network 38
Configuring the router to act as a Nortel VPN Server (Client Termination) . . . 39
Configuring the router to connect to a Nortel VPN Server (Client Emulation) . 39
Allowing remote management of a LAN-connected BCM50 39
Setting up the router for guest access 40
Preventing heavy data traffic from impacting telephone calls 40
Setting Up a Remote Office with a UNIStim IP Telephone 41
Inter-Operability With Third-Party Routers 42
VPN Connections With Cisco Routers 42

Chapter 6
Troubleshooting 43

Problem: None of the LEDs turn on when you turn on the Business Secure Router 43
Problem: You cannot access the Business Secure Router from the LAN 43
Problem: You cannot ping any computer on the LAN 43
Problem: You cannot get a WAN IP address from the ISP 44
Problem: You cannot access the Internet 44

Table 1	Internet Account Information Worksheet	11
Table 2	Front panel details	14
Table 3	Rear panel details	15

Preface

This Quick Start Guide provides instructions for installing and configuring your Nortel Business Secure Router 252 as an Office Gateway for your network. After completing this guide, you can access the Internet securely through your Nortel Business Secure Router 252.

Before you begin

This guide is intended for network managers who are installing the Nortel Business Secure Router 252 for the first time. It assumes that you are familiar with the type of Internet connection used with your Business Secure Router.

Text conventions

This guide uses the following text conventions:

italic text	Indicates new terms, book titles, and variables in command syntax descriptions. Where a variable is two or more words, the words are connected by an underscore. Example: If the command syntax is `show at <valid_route>`, `valid_route` is one variable and you substitute one value for it.

Acronyms

This guide uses the following acronyms:

ADSL	asymmetric digital subscriber line
DHCP	Dynamic Host Configuration Protocol
DNS	domain name server

ENET	Ethernet
IP	Internet Protocol
ISP	Internet Service Provider
LAN	local area network
LLC	logical link control
PPPoA	Point-to-Point Protocol over ADSL
PPPoE	Point-to-Point Protocol over Ethernet
RFC	request for comment
SUA	single user account
TCP/IP	Transmission Control Protocol/Internet Protocol
VC	virtual channel
VCI	virtual channel identifier
VPI	virtual path identifier
WAN	wide area network

Related publications

For more information about using the Nortel Business Secure Router 252, refer to the following publication:

- *Nortel Business Secure Router 252 - Basics* (NN47923-500)

Hard-copy technical manuals

You can print selected technical manuals and release notes free, directly from the Internet. Go to www.nortel.com/documentation. Find the product for which you need documentation. Then locate the specific category and model or version for your hardware or software product. Use *Adobe Reader* to open the manuals and release notes, search for the sections you need, and print them on most standard printers. Go to the Adobe Systems web site at www.adobe.com to download a free copy of Adobe Reader.

How to get help

If you purchased a service contract for your Nortel product from a distributor or authorized reseller, contact the technical support staff for that distributor or reseller for assistance.

If you purchased a Nortel service program, contact Nortel Technical Support. To obtain contact information online, go to www.nortel.com/cgi-bin/comments/comments.cgi, then click on Technical Support.

From the Technical Support page, you can open a Customer Service Request online or find the telephone number for the nearest Technical Solutions Center. If you are not connected to the Internet, you can call 1-800-4NORTEL (1-800-466-7835) to learn the telephone number for the nearest Technical Solutions Center.

An Express Routing Code (ERC) is available for many Nortel products and services. When you use an ERC, your call is routed to a technical support person who specializes in supporting that product or service. To locate an ERC for your product or service, go to http://www.nortel.com/help/contact/erc/index.html.

Chapter 1
Introducing the Business Secure Router

The Nortel Business Secure Router 252 is the ideal secure gateway for all data passing between the Internet and the LAN. By integrating Network Address Translation (NAT), firewall and Virtual Private Network (VPN) capability, the Nortel Business Secure Router 252 is a complete security solution that protects your Intranet and efficiently manages data traffic on your network. The embedded WebGUI is easy to operate and totally independent of the operating system platform you use.

You must have an Internet account already set up and have most of the following information.

Table 1 Internet Account Information Worksheet

INTERNET ACCOUNT INFORMATION		
Your device's WAN IP Address (if given): _____		WAN Subnet Mask: _____
DNS Server IP Address (if given): First _____, Second _____, Third _____		
Virtual Path Identifier (**VPI**): _____		
Virtual Channel Identifier (**VCI**): _____		
Multiplexing (VC-based or LLC-based):	☐ VC	☐ LLC
Encapsulation (select one below):		
○ **PPPoE**	Service Name: _____	
	User Name: _____	Password: _____
○ **RFC 1483**		
○ **ENET ENCAP**	ENET ENCAP Gateway IP Address: _____	
○ **PPPoA**	User Name: _____	Password: _____

Chapter 2
Hardware installation

Caution: To keep the Business Secure Router operating at optimal internal temperature, keep the bottom, sides, and rear clear of obstructions and away from the exhaust of other equipment.

Caution: AC Power Adapter Specifications
Only use the approved Phihong Model PSA21R-180 power supply with this device.
NOTE: Attach the appropriate plug to the power supply first before inserting it into the power outlet.

Caution: Electro-static Discharge can disrupt the router. Use appropriate handling precautions to avoid ESD. Avoid touching the connectors on the router, particularly when it is in use.

Note: Please use only No. 26 AWG (American Wire Gauge) or larger telecommunication line cord.

2.1 Front panel



Table 2 Front panel details

LABEL	DESCRIPTION
Step 1: 1-4	Connect a computer to one of these ports with an Ethernet cable. These ports are auto-negotiating (can connect at 10 or 100Mb/s) and auto-sensing (automatically adjusts to the type of Ethernet cable you use, straight-through or crossover).
Step 2 	Connect this port to an ADSL-enabled telephone jack (or DSL splitter).

2.2 Rear panel



Table 3 Rear panel details

LABEL	DESCRIPTION
Step 3 18V DC	Connect the included power adaptor (use only this adapter) to this power socket.
After you have made the connections, connect the power cable to a power supply and look at the front panel LEDs. The power LED blinks while performing system testing and then stays on if the testing is successful. The Ethernet port LEDs turn on if the ports are properly connected. Refer to *Configuring and Troubleshooting the Nortel Business Secure Router 252* for more detailed LED descriptions.	
port, switch	Only connect this port if you want to configure the Business Secure Router using the SMT via console port. See your User's Guide for details. Set this switch to the CON (Console) side to use the CON/AUX port as a console port for local device configuration and management. Connect the 9-pin male end of the console cable to the console port of the Business Secure Router and the other end to a serial port (COM1, COM2 or other COM port) on your computer. Your computer must have a terminal emulation communications program (such as HyperTerminal) set to VT100 terminal emulation, no parity, 8 data bits, 1 stop bit, no flow control and 9600 b/s port speed.
(no label)	Press this button for one to three seconds to restart the Business Secure Router. Press this button for longer than three seconds to return the Business Secure Router to the factory defaults (password is PlsChgMe!, LAN IP address 192.168.1.1, terminal emulation settings as described above; see your User's Guide for details).

Chapter 3
Setting up your computer IP address

The Business Secure Router is already set up to assign your computer an IP address. Use this section to set up your computer to receive an IP address or assign it a static IP address in the 192.168.1.2 to 192.168.1.127 range with a subnet mask of 255.255.255.0. This is necessary to ensure that your computer can communicate with your Business Secure Router.

Your computer must have an Ethernet card and TCP/IP installed. TCP/IP must already be installed on computers using Windows NT/2000/XP or Macintosh OS 7 and later operating systems. Instructions are provided here for configuring Windows 2000, NT and XP operating systems. Refer to *Nortel Business Secure Router 252 Configuration — Basics* (NN47923-500) and *Nortel Business Secure Router 252 Configuration — Advanced* (NN47923-501) for detailed IP address configuration for Windows 95, 98, Me and Macintosh and Linux computer operating systems.

3.1 Static or dynamic configuration (Windows 2000/NT/XP)

1. In Windows XP, click **Start**, **Control Panel**.
   a. In Windows 2000/NT, click **Start**, **Settings**, **Control Panel**.
2. In Windows XP, click **Network Connections**.
   a. In Windows 2000/NT, click **Network and Dial-up Connections**.
3. Right-click **Local Area Connection** and then click **Properties.**
4. Select **Internet Protocol (TCP/IP)** (under the General tab in Windows XP) and click **Properties.**
5. The Internet Protocol TCP/IP Properties screen appears (the General tab in Windows XP).
   a. To have your computer assigned a dynamic IP address, click **Obtain an IP address automatically**.
   b. To configure a static IP address, click **Use the following IP Address** and fill in the IP address (choose one from 192.168.1.2 to 192.168.1.127), Subnet mask (255.255.255.0), and Default gateway (192.168.1.1) fields.

Nortel recommends that you do not use a static IP address in the same range as the Business Secure Router DHCP server address pool (192.168.1.2 to 192.168.1.127 by default).


Internet Protocol (TCP/IP) Properties
General
Alternate Configuration
You can get IP settings assigned automatically if your network supports this capability. Otherwise, you need to ask your network administrator for the appropriate IP settings.
Obtain an IP address automatically
Use the following IP address:
IP address:
Subnet mask:
Default gateway:
Obtain DNS server address automatically
Use the following DNS server addresses:
Preferred DNS server:
Alternate DNS server:
Advanced...
OK
Cancel

6 Click **Advanced**. Remove any previously installed gateways in the IP Settings tab and click **OK** to go back to the Internet Protocol TCP/IP Properties screen.



7 Click **Obtain DNS server address automatically** if you do not know your DNS server IP address(es).

   a If you know your DNS server IP addresses, click **Use the following DNS server addresses**, and type them in the Preferred DNS server and Alternate DNS server fields.

   b If you have more than two DNS servers, click **Advanced**, select the DNS tab and then configure the two DNS servers using the **Add** button.

8 Click **OK** to close the Internet Protocol (TCP/IP) Properties window.

9 Click **OK** to close the Local Area Connection Properties window.

3.2 Checking your computer IP address

1 On your computer, click **Start, (All) Programs**, **Accessories** and then **Command Prompt.**

2 In the Command Prompt window, type **ipconfig** and then press **Enter**. Your computer IP address must be in the correct range (192.168.1.2 to 192.168.1.254), with subnet mask 255.255.255.0, in order to communicate with the Business Secure Router.

Refer to *Nortel Business Secure Router 252 Configuration — Basics* (NN47923-500) and *Nortel Business Secure Router 252 Configuration — Advanced* (NN47923-501) for detailed IP address configuration for other Windows and Macintosh computer operating systems.

Chapter 4
Configuring your Business Secure Router

Choose one of these methods to access and configure the Business Secure Router. This guide shows you how to use the WebGUI wizard only. See *Nortel Business Secure Router 252 Configuration — Basics* (NN47923-500) and *Nortel Business Secure Router 252 Configuration — Advanced* (NN47923-501) for background information about all Business Secure Router features and SMT configuration. Click the WebGUI online help for screen-specific web help.

4.1 Accessing your Business Secure Router via the WebGUI

1 Launch your web browser. Enter **192.168.1.1** as the web site address.



2 Enter the default username (**nnadmin**) and password (**PlsChgMe!**). Click **Login** to proceed to a screen that will let you to change your password. Click **Reset** if you want to clear any information you have entered in the **Username** and **Password** fields.



3 Nortel recommends you change the default password! Enter a new password, retype it to confirm it and click **Apply**. Alternatively click **Ignore** to proceed to the main menu if you do not want to change the password now.



4 Click **Apply** in the **Replace Factory Default Certificate** screen to create a certificate using your Business Secure Router MAC address, which will be specific to this device.


NORTEL
Replace Factory Default Certificate
The factory default certificate is common to Business Secure Router series models. Click Apply to create a certificate using your Business Secure Router 's MAC address that will be specific to this device.
Apply
Ignore

5 The WebGUI MAIN MENU screen appears.

- Select **WIZARD** if you want help configuring your Business Secure Router for the first time.
- Select a link under **MAIN MENU** in the navigation panel to configure a Business Secure Router feature.
- Select **MAINTENANCE** in the navigation panel to view Business Secure Router performance statistics, upload firmware and back up information or restore or upload a configuration file.
- Click **LOGOUT** when you have finished a Business Secure Router management session. The Business Secure Router automatically logs you off if the session is left idle for five minutes. Click **ENTER** to display the Login screen again and then log back on. This idle timeout timer is one of the many Business Secure Router features that you can edit using the WebGUI.



4.2 Using the wizard to configure for internet access

1 Select **WIZARD** to display the first wizard screen.



From the **Mode** drop-down list box, select **Routing** (default) if your ISP allows multiple computers to share an Internet account. Otherwise select **Bridge**.

Select the **encapsulation** type your ISP uses from the Encapsulation drop-down list box. Choices vary depending on what you select in the Mode field.

Select the **multiplexing** method used by your ISP from the Multiplex drop-down list box.

Enter the correct Virtual Path Identifier (VPI) and Virtual Channel Identifier (VCI) numbers supplied by your ISP in the **VPI** and **VCI** fields. These fields may already be configured.

Click **Next**.

2 The second wizard screen varies depending on what mode and encapsulation type you use. All screens shown are with routing mode. Configure the fields and click **Next** to continue.



Internet Connection with PPPoE

If your ISP provides the name of your PPPoE service provider, enter it in the **Service Name** field.

Enter the user name and password exactly as your ISP gives you.

Select **Obtain an IP Address Automatically** if you have a dynamic WAN IP address; otherwise select **Static IP Address** and type your ISP assigned WAN IP address in the text box below.

Select **Connect on Demand** when you don't want the connection up all the time and specify an idle time-out period (in seconds) in the **Max. Idle Timeout** field.

Select **Nailed-Up Connection** when you want your connection up all the time. The Business Secure Router will try to bring up the connection automatically if it is disconnected.

From the **Network Address Translation** drop-down list box, select **SUA Only, Full Feature** or **None**.



Internet Connection with RFC 1483

Enter the IP address given by your ISP in the **IP Address** field.

From the **Network Address Translation** drop-down list box, select **SUA Only, Full Feature** or **None**.



Internet Connection with ENET ENCAP

Select **Obtain an IP Address Automatically** if you have a dynamic WAN IP address; otherwise select **Static IP Address** and type your ISP assigned WAN IP address and the subnet mask in the fields provided.

In the **ENET ENCAP Gateway** field, enter the gateway IP address given by your ISP.

From the **Network Address Translation** drop-down list box, select **SUA Only, Full Feature** or **None**.



Internet Connection with PPPoA

Refer to "Internet Connection with PPPoE" on page 26 for field descriptions.

3 Verify the settings in the screen shown next. This screen varies depending on what mode and encapsulation type you use. To change the LAN information on the Business Secure Router, click **Change LAN Configurations**. Otherwise click **Save Settings** to save the configuration and skip to step 5.



If you want to change your Business Secure Router LAN settings, click **Change LAN Configuration** to display the screen as shown next

.



4 Enter the IP address of your Business Secure Router in dotted decimal notation in the **LAN IP Address** field. For example, 192.168.1.1 (factory default).

Note: If you change the Business Secure Router's LAN IP address, you must use the new IP address if you want to access the WebGUI again.

Enter a subnet mask in dotted decimal notation in the LAN **Subnet Mask** field.

From the **DHCP Server** drop-down list box, select **Server** to allow your Business Secure Router to assign IP addresses, an IP default gateway and DNS servers to computer systems that support the DHCP client. Select **Relay** to have the Business Secure Router forward DHCP requests to another DHCP server. When set to **Relay**, fill in the **DHCP Server Address** field.

Select **None** to stop the Business Secure Router from acting as a DHCP server. When you select **None**, you must have another DHCP server on your LAN, or else the computers must be manually configured.

When **DHCP** server is used, set the following items:

Specify the first of the contiguous addresses in the IP address pool in the Client **IP Pool Starting Address** field.

Specify the size or count of the IP address pool in the **Size of Client IP Pool** field.

When DHCP relay is used, set the following:

Type the IP address of the DHCP server in dotted decimal notation (like 192.168.1.5) in the **DHCP Server Address** field.

To configure the DNS server settings:

Select **Obtained From ISP** if your ISP dynamically assigns DNS server information (and the Business Secure Router WAN IP address). The field to the right displays the (read-only) DNS server IP address that the ISP assigns.

Select **UserDefined** if you have the IP address of a DNS server. Enter the DNS server IP address in the field to the right.

Select **DNS Relay** to have the Business Secure Router act as a DNS proxy. The Business Secure Router LAN IP address displays in the field to the right (read-only). The Business Secure Router tells the DHCP clients on the LAN that the Business Secure Router itself is the DNS server. When a computer on the LAN sends a DNS query to the Business Secure Router, the Business Secure Router forwards the query to the Business Secure Router system DNS server (configured in the **SYSTEM General** screen) and relays the response back to the computer. You can only select **DNS Relay** for one of the three servers;

Select **None** if you do not want to configure DNS servers. If you do not configure a DNS server, you must know the IP addresses of devices or web sites in order to access them.

5 The Business Secure Router automatically tests the connection to the computer(s) connected to the LAN ports. This screen varies depending on what mode and encapsulation type you use. To test the connection from the Business Secure Router to the ISP and the connected LAN device(s), click **Start Diagnose**. Otherwise click **Finish** to go back to the **Site Map** screen.

.


Wizard Setup - ISP Parameters for Internet Access
Your DSL Gateway is now configured. Your device is capable of testing your DSL service. The individual tests are listed below. Click "Start Diagnose" button if you want to test; otherwise, click "Finish" button.
LAN connections
Test your Ethernet Connection PASS
WAN connections
Test ADSL synchronization PASS
Test ADSL(ATM OAM) loopback test PASS
Test PPP/PPPoE server connection PASS
Ping default gateway PASS
Start Diagnose
Finish

4.3 Test your internet connection

Launch your web browser and go to www.nortel.com. You do not need a dial-up program such as Dial-Up Networking. Internet access is just the beginning. Refer to the *Nortel Business Secure Router 252 Configuration — Basics* (NN47923-500) and *Nortel Business Secure Router 252 Configuration — Advanced* (NN47923-501) for more detailed information about the complete range of Nortel Business Secure Router 252 features.

Chapter 5
User Notes

General Notes

There are some router functions that, although performing as expected, might cause some confusion. These are summarized below.

General

1 Default Address Mapping Rules When First Enable NAT Full Feature.

When NAT Full Feature is first enabled, two address mapping rules are added to the address mapping table. This is done to facilitate programming, and matches the default SUA rule. The rules can be deleted.

2 Response to Invalid User ID or Password

When the wrong user ID or password is entered into the router login screen, no error message is displayed. Instead, the login screen is simply displayed again.

3 First DHCP Address Reserved for BCM50

The first address of the DHCP Address Pool is reserved for a BCM50 in the subnet, and will not be assigned to any other equipment. Once assigned to a BCM50, it is reserved for that BCM50, and will not be assigned to any other. If the BCM50 is changed, the following command must be used to enable the router to assign the first address to a different BCM50:

```
ip dhcp enif0 server m50mac clear
```

4 Login Requires Reboot

If the Administrator Timeout is set to 0, and an administration session is terminated without logging off, the router needs to be rebooted in order for the administrator to log in to the WebGUI again. Alternatively, the administrator can log in using a TelNet session, if TelNet access has been enabled in the Remote Management menu.

5 Clicking Sound

The Business Secure Router will click once every two minutes until an ADSL line is connected.

Firewall

1 Address Range Validation

In the firewall rules, the router does not confirm when given an address range, that the second address is higher than the first. If this type of address range is entered, the range is ignored.

2 Automatic Firewall Programming

Configurations to various areas of the router, such as remote management or adding a SUA Server, do not automatically add the appropriate rules to the Firewall, to enable the traffic to pass through the router. These need to be added separately.

Note: Firewall rules do not apply to IPSec tunnels.

NAT

1 Deleting NAT Rule Does Not Drop an Existing Connection

If a NAT rule is deleted, the router must be rebooted to apply the change to existing service connections. This is already noted in the GUI.

2 NAT Traversal Status

If NAT Traversal is enabled, but is not needed (because the client is not behind a NAT router), it will be shown as 'inactive' in the VPN Client Monitor. This may confuse some users.

VPN Client Termination

1 Change of User Account Does Not Drop Existing Connections

If a VPN Client user account is de-activated, deleted, or changed, and that user is currently connected, the connection is not automatically dropped. To drop the connection, the administrator needs to disconnect the user using the 'Disconnect' function in the VPN/SA Monitor GUI. This is consistent with other Nortel Contivity products.

2 User Name Restrictions

User names are limited to a maximum length of 63 characters.

3 VPN Client Account Password Restrictions

The password for a VPN Client user cannot contain the single- or double-quote characters.

4 IP Pool Address Overlap

When defining multiple VPN Client Termination IP pools, the router uses the IP Subnet mask, and not the pool size, to determine if the pools are overlapping. The subnet mask of each pool should be appropriate for the size of the VPN Client Termination IP pool.

5 VPN Client Termination - Failure In Specific Addressing Situation

If the Client has an assigned IP address that is the same as the IP address assigned for the Client Tunnel, the connection will fail to be established.

6 VPN Client Termination - Configuration Restrictions

This router has some restrictions when compared to larger Contivity Routers (1000 Series and above). In particular,

VPN Clients cannot be added to the LAN subnet. They must have addresses outside of the LAN subnet.

VPN Clients can have dynamically assigned IP addresses, or they can have a statically assigned addresses. However, the router does not support both modes at once. All addresses must either be dynamically assigned, or they must all be statically assigned.

7 Establishing a Client Tunnel From One Business Secure Router to Another

When defining a Client Termination account for another Business Secure Router that will connect using Contivity Client Emulation, the following configuration is required:

- Encryption must be Triple DES with SHA1 integrity, or Triple DES with MD5 integrity.
- IKE Encryption must be Triple DES with Diffie-Hellman Group 2.
- Perfect Forward Secrecy (PFS) must be enabled.

Security

1 Exporting or Saving Self-Signed Certificate

To export or save a self-signed certificate, click details (the icon that looks like a paper note), then click 'Export' or copy the PEM text into the clipboard, and paste into a file.

Routing

1 RIP Version Advertisement Control

To change the version of generated RIP advertisements, the following CLI command needs to be used

ip rip mode [enif0|enif1] [in|out] [0|1|2|3]

where:

'enif0' is the LAN side, and 'enif1' is the WAN side

'in' affects recognition of received advertisements, and

'out' applies to generated advertisements

The number controls the operating mode:

None (disabled)

RIP-1 only

RIP-2 only

Both RIP-1 and RIP-2

Advanced Router Configuration

The following notes are intended to help with advanced router configuration.

Setting up the router when the system has a server

1. If you are using a Full-Feature NAT configuration, first, do the following...
   - **a** In SUA/NAT / Address Mapping, add a 'Server' rule, specifying the 'Public' IP address of the server.
2. For both SUA-Only and Full-Feature NAT configurations, do the following...
   - **a** In SUA/NAT : SUA Server, add server private IP address and port number(s) to the SUA/NAT Server table.
   - **b** In FIREWALL, add a WAN-to-LAN rule
   - **c** If the service is not in the list of available services, add it as a 'Custom Port'.
   - **d** Add the rule, selecting the service, and entering the server IP address as the destination IP address.

Connecting two sites to establish a virtual private network

The recommended method to do this is through a branch-to-branch IPSec tunnel.

1. In VPN / Summary, add a new tunnel by editing an unused rule. Create an Active, Branch Office tunnel.
   - **a** Select 'Nailed Up' if the tunnel should not be closed while not in use.
   - **b** Enter the authentication information, with either a pre-shared key or an imported certificate.
   - **c** Enter the IP Address assigned to the router WAN port. This should be a static address, or a dynamic DNS name, and the IP address of the remote router.
   - **d** Select the encryption and authentication algorithms.
   - **e** Add an IP policy, by specifying the IP address ranges of the local and remote hosts that will use the tunnel.

2 Repeat these steps at the other end of the branch.

Note: If VPN Client Termination is used on these sites, the client termination address range will need to be included in the tunnel policies in order for the VPN clients to see the other site.

Adding IP telephony to a multi-site network

Scenario 1: A BCM50 in the primary site acting as the gateway for both sites

1 Ensure that the DHCP Server in the BCM50 is disabled, that the BCM50 is connected to the router, and both have booted.

2 Add the IP phones to the primary site as per BCM50 installation guide.

3 Create a tunnel to the remote site, as described above.

4 In the remote site, set the S1 and S2 addresses to the IP address of the BCM50, which is identified in the router DHCP table or in the BCM50. This is done with a CLI command.

TELNET or SSH to the router. This needs TELNET or SSH enabled on that router. Select menu 24, select menu 8, and enter the commands:

ip dhcp enif0 server voipserver 1 <BCM50_IP_Address> 7000 1

ip dhcp enif0 server voipserver 2 <BCM50_IP_Address> 7000 1

5 Add the IP phones to the remote site, configured for full DHCP client mode.

Scenario 2: A BCM50 in each site, each acting as the backup call server for the other site

1 At each site,

a Ensure that the DHCP Server in the BCM50 is disabled, that the BCM50 is connected to the router, and both have booted.

b Add the IP phones to the site as per BCM50 installation guide.

c At each router, change the S2 address to the IP address of the remote BCM50, using TELNET or SSH, and the CLI command,

ip dhcp enif0 server voipserver 2 <Remote_BCM50_IP_Address> 7000 1

2 Create a tunnel between the sites, as described above.

3 Create an H.323 trunk between the BCM50s, as per the BCM50 User Guide.

Configuring the router to act as a Nortel VPN Server (Client Termination)

1 Under VPN / Client Termination,

   a Enable Client Termination.

   b Select authentication type and the encryption algorithms supported.

   c If the clients are assigned IP addresses from a pool, define the pool, and enable it.

2 Assuming a Local User Database is used for authentication,

   a Add user name and password to the local user database as an IPSec user, and activate it. If the hosts will be assigned a static IP address, enter the address that will be assigned to the user.

Configuring the router to connect to a Nortel VPN Server (Client Emulation)

1 Go to VPN / Summary, and select 'Edit'.

2 Select a connection type of Contivity Client, and fill in the web page with the relevant data.

3 If Group authentication or On-Demand Client Tunnels are needed, click the 'Advanced' button to configure this.

Allowing remote management of a LAN-connected BCM50

1 Create the appropriate NAT server rules to add the BCM50.

Go to SUA/NAT / SUA Server, and create two server rules for HTTPS and Element Manager access:

One named BCM_HTTPS, with port number 443, and the IP address of the BCM50

One named BCM_EM, with the port number 5989, and the IP address of the BCM50

Note: In DHCP Server mode, the BCM50 IP address will be the lowest address in the pool.

2 Create the appropriate Firewall rules to add BCM50 access.

Go to FIREWALL / Summary, and create two WAN-to-LAN firewall rules:

One rule allowing access from allowed remote computer IP addresses, to the BCM50 IP address, for service type HTTPS(TCP:443)

One rule allowing access from allowed remote computer IP addresses, to the BCM50 IP address, for custom port TCP:5989

Setting up the router for guest access

The recommended approach to provide guest access is by creating an IP Alias, and using static addressing for the corporate equipment, to make it a member of the defined Alias subnet. Then use firewall rules to restrict access of the guest equipment. NOTE: if a BCM50 is used, it will also need to be assigned a static IP address.

1 Go to LAN / IP Alias, and Enable IP Alias 1.

2 Define a subnet for the corporate equipment.

3 Statically assign addresses to the corporate equipment that are within the IP Alias subnet.

4 Set up LAN / IP to enable DHCP Server, with an address range that will be used for guest equipment.

5 In the FIREWALL, set up a LAN-to-LAN rule to block traffic between the guest subnet (DHCP Pool) and the corporate subnet (IP Alias subnet).

Note: If branch tunnels are being used, the policies on these tunnels should exclude the guest subnet.

Preventing heavy data traffic from impacting telephone calls

To ensure voice quality during heavy data traffic, bandwidth needs to be reserved for voice traffic.

1 Determine your actual WAN up-stream bandwidth by connecting to a web site such as http://myvoipspeed.visualware.com/.

2 On BANDWIDTH MANAGEMENT / Summary, activate WAN bandwidth management, and fill in your actual uplink speed in the WAN Speed field..

3 On BANDWIDTH MANAGEMENT / Class Setup, add a WAN subclass, and reserve sufficient bandwidth based on the number of telephones, for Protocol ID 17 (UDP Traffic).

   The amount of bandwidth should be based on a reasonable peak number of simultaneous calls, and the data rate needed by the IP telephony CODECs.

Setting Up a Remote Office with a UNIStim IP Telephone

For a remote office with a PC, and a UNIStim IP telephone behind a BCM50a Integrated Router, Client Emulation is the recommended method to connect to the main office.

1 At the main office Contivity Client Server, establish two user accounts - one for the telephone, and one for the PC.

2 On the remote office BCM50a Integrated Router, do the following:

   Under WAN / WAN IP, ensure that Network Address Translation is set to SUA Only (default). Also ensure that the Gateway IP address is set (not 0.0.0.0).

   Under VPN / Summary, create an entry for the IP telephone client tunnel. (Contivity Client, Active, Keep Alive). Fill in the IP address of the Contivity Client Server, and the name and password of the telephone set user account.

   Under VPN / Global Setting, enable Exclusive Mode, and fill in the MAC address of the telephone set.

   Under Bandwidth Management, set up WAN bandwidth management to reserve 110 kbps of bandwidth for UDP traffic (protocol ID 17). See the preceding section titled, “Preventing heavy data traffic from impacting telephone calls”.

3 Provision the IP set with the corporate call server address.

4 On the PC, install Contivity Client Software, and configure it with the PC user account information.

Inter-Operability With Third-Party Routers

VPN Connections With Cisco Routers

When establishing a VPN Client tunnel or Branch Office Tunnel between the Business Secure Router and a Cisco router, the following configuration rules should be followed:

1. Ensure that the WAN IP of the BSR222/252 router and the Cisco router are not in the same subnet.
2. Configure the connection to use DES Encryption and MD5 Authentication.

Chapter 6 Troubleshooting

Problem: None of the LEDs turn on when you turn on the Business Secure Router

Make sure that you have the correct power adapter connected to the Business Secure Router and that it is plugged in to an appropriate power source. Check all cable connections.

If the LEDs still do not turn on, you may have a hardware problem. In this case, contact your local vendor.

Problem: You cannot access the Business Secure Router from the LAN

Check the cable connection between the Business Secure Router and your computer or hub. Refer to the Rear Panel section for details.

Ping the Business Secure Router (the default IP address is 192.168.1.1) from a LAN computer. Make sure your computer Ethernet card is installed and functioning properly.

Problem: You cannot ping any computer on the LAN

If the LAN LEDs are off, check the cable connections between the Business Secure Router and your LAN computers.

Verify that the IP address and subnet mask of the Business Secure Router and the LAN computers are in the same IP address range. See "3.1 Static or dynamic configuration (Windows 2000/NT/XP)" on page 17 for details about how to change your computer's IP address with Windows 2000, NT and XP operating systems. Refer to *Configuring and Troubleshooting the Nortel Business Secure Router 252* for detailed IP address configuration for Windows 95, 98, Me and Macintosh and Linux computer operating systems.

Problem: You cannot get a WAN IP address from the ISP

The ISP provides the WAN IP address after authenticating the username and password, the MAC address, or the host name. Find out the verification method used by your ISP.

You need a username and password if you are using PPPoE or PPPoA encapsulation. Make sure that you have entered the correct service type, username, and password (the username and password are case-sensitive). Use the wizard screens or the **WAN** screens in the WebGUI.

If the ISP checks the MAC address, make sure the ISP is checking for the MAC address of the Business Secure Router.

If your ISP requires host name authentication, configure your computer name as the system name of the BCM50a Integrated Router (use the **System General** screen to configure the system name).

Problem: You cannot access the Internet

Check the Business Secure Router connection to the ADSL-enabled telephone jack (or DSL splitter).

Click **WAN** and verify your settings.